

DK: Brugsanvisning:

Kan tilsluttes til PC både via USB kabel og via trådløs dongle til USB.

Kan tilkobles til mobilenhed via bluetooth.

Ved opstart bør den indstilles til "International" ved at skanne strekkoden nedenfor:



International Universal Keyboard

Valg af skanner funktionalitet skiftes ved at skanne en af følgende:



Sensor mode



Continuous mode



Manual mode

NO: Bruksanvisning:

Kan kobles til PC både via USB-kabel og via trådløs USB-dongle.

Kan kobles til mobilenhet via Bluetooth.

Ved oppstart bør den settes til "International" ved å skanne strekkoden nedenfor:



International Universal Keyboard

Valg av skannerfunksjonalitet byttes ved å skanne en av følgende:



Sensor mode



Continuous mode



Manual mode

SE: Bruksanvisning:

Kan anslutas till PC både via USB-kabel och via trådlös USB-dongel.

Kan anslutas till mobila enheter via Bluetooth.

Vid uppstart bör den ställas in på "International" genom att skanna streckkoden nedan:



International Universal Keyboard

Val av skannerfunktionalitet ändras genom att skanna en av följande:



Sensor mode



Continuous mode



Manual mode

EN: User Manual:

Can be connected to a PC either via USB cable or wireless USB dongle.

Can be connected to a mobile device via Bluetooth.

At startup, it should be set to "International" by scanning the barcode below:



International Universal Keyboard

To select scanner functionality, scan one of the following:



Sensor mode



Continuous mode



Manual mode

